

RANCH HAND

1-800-366-9712

INSTALLATION INSTRUCTIONS

2003 - 2007(Classic) CHEVY 1500 SUMMIT SERIES RECEIVER HITCH

PART # RHC03HBL1

2003 - 2007(Classic) GMC 1500 SUMMIT SERIES RECEIVER HITCH

PART # RHG03HBL1

1. After installing Summit series front bumper replacement (FSC03HBL1) or (FSG031BL1), place receiver hitch with the receiver facing towards the radiator up past the mounting bracket.
2. Turn receiver hitch 180 degrees until receiver hitch is facing to the front.
3. Place ½” bolts through the mounting bracket and receiver hitch bracket. Hand tighten.
4. Place other ½” bolts through the receiver hitch bracket and upright. Hand tighten.
5. Level receiver hitch and check to see if receiver is centered through the rectangle hole of the front floor plate. Tighten bolts.
6. Install the spring hinge to the slotted holes in the front center floor plate. Then mount the license plate to the spring hinge with the bolt facing forward.
7. **MAKE SURE ALL NUTS AND BOLTS ARE TIGHT.**

WARNING

Special care should be exercised in the handling, storage and installation of Kaspar Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment.

Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 10/14/08